

# FITTING GUIDE

## KM045 – OVAL ESCUTCHEON

LIT-FG-FX-KM045

1



Machine out the Euro Profile cylinder cut out, also drill 2 x 2.5mm holes 15mm deep to accept the screws.

2



Take the back plate and fix to the door using the screws provided, tighten until firm.

3



Once tightened, take the cover plate and push firmly over the backplate until flush with the door.

4



You can now install the cylinder to complete the installation.



# COASTAL

*Shaping the future.*