


DOOR HARDWARE

MULTIPOINT LOCK LATCH RELEASE

Non-handed (Universal) Multipoint Lock


Winkhaus Multipoint Locks



Undo this screw several turns until the latch mechanism can be turned through 180 degrees to alter the handing.

Once altered, tighten the screw to secure

MACO TRICOAT Multipoint Locks



Push this switch down until the latch mechanism can be removed then turned through 280 degrees to alter the handing.

Once altered push the latch back in and press the switch down to lock making sure the switch flicks back into lock position.

How to release the latch on a non-handed (universal) multipoint lock

The drawings above demonstrates how to change the latch on a non-handed (universal) lock from a left hand to a right hand.



COASTAL

Shaping the future.