

blueMatic AV2-E

Wiring Options




Coastal Specialist Ironmongery Ltd

Global House, Bojea Industrial Estate,
Trethowel,
St Austell,
Cornwall, PL255RJ


Telephone: 01726 871025

Email: sales@coastal-group.com

AV2-E Entrance Door Lock Wiring diagram for Access Control



AV2-E Entrance Door Lock Wiring diagram for Push Switch



All switching devices - Wires must be potential free "Clean Wires"